

Safety Valve HSV

Installation, maintenance and startup guide



© 2011 by Hydronic Lift Spa

All right reserved. This documentation, in whole and/or in part, is protected by copyright. It may not be reproduced, nor may it stored, processed, replicated, or distributed by electronic means, without written permission of Hydronic Lift.

Data is provided for the purpose of product description only, and must not be construed as warranted characteristics in the legal sense. No assertion regarding either a particular property or the fitness for a particular intended purpose can be derived or deduced from this information. The information does not relieve users from the duty of conducting their own evaluation and tests. Because the products are subject to continual improvement, we reserve the right to amend the product specifications contained in this manual. The original language and legal terminology for all Hydronic Lift documentation is Italian. Hydronic Lift cannot be held liable for any possible errors in translation.

Summary

Summary.....	3
1 General purpose and important notes	5
1.1 Conformity	5
1.2 Intended use	5
2 Description of Safety Valve HSV	6
2.1 Configurations.....	6
2.2 Hydraulic and electrical diagram	6
2.3 Control Valve characteristics for connection with Security Valve HSV.....	7
2.3.1 Example 1: control valve H300 hydraulic scheme with safety valve HSV	8
2.3.2 Example 2: control valve C-LRV hydraulic scheme with safety valve HSV	9
2.4.1 Integration of the safety valve HSV into the lift control.....	10
2.4.1.1 <i>State of the Safety Valve's solenoid vs. State of the lift</i>	10
2.4.1.2 <i>Sequence of signals at normal operation for control valve H300</i>	11
2.4.1.3 <i>Sequence of signals at normal operation for control valve ESC</i>	12
2.4.1.4 <i>Sequence of signals at normal operation for control valve C-LRV</i>	13
2.4.1.5 <i>Positioning of the shaft switches d_{max}</i>	14
2.4.1.6 <i>Function of the Safety Valve HSV in case of an unintended travel DOWN</i>	16
2.5 Technical data	17
2.5.1 Working limits	17
2.5.2 Port and Dimensions HSV-150 e HSV-440.....	17
2.5.3 Label.....	18
2.5.4 Solenoid's wiring	19
2.5.5 Pressure switch.....	21
2.5.5.1 <i>Pressure switch selection</i>	21
3 Installation and commissioning	22
3.1 Electrical installation.....	22
3.2 Start up	22
4 Installation as modernization kit	23
4.1 Mechanical installation of safety Valve HSV	23
4.1.1 Mechanical installation with control valve H300	23
4.1.2 Mechanical installation with control valve C-LRV	26
4.2 Change of pressure switch position	29
4.2.1 H300 control valve.....	29
4.2.1.1 <i>Single pressure switch configuration.</i>	29
4.2.1.2 <i>Double pressure switches configuration.</i>	29
4.2.1.3 <i>Triple pressure switches configuration.</i>	30
4.2.2 C-LRV control valve.....	31
4.2.2.1 <i>Single pressure switch configuration.</i>	31
4.2.2.2 <i>Double pressure switches configuration.</i>	31
4.2.2.3 <i>Triple pressure switches configuration.</i>	32
5 Operation	33
5.1 Normal operation	33

5.2 Manual operation	33
6 Check the correct functioning of HSV valve	34
6.1 Leakage test of the valve seat	34
6.2 Simplified functional test	35
7 Repair	35
7.1 Replacement of the solenoid coil	35

1 General purpose and important notes

The Safety Valve HSV installation, maintenance and start up guide is an integral part of the product HSV. It describes the product's safe use and maintenance in all operative phases and is valid for all models that are referred to.

This guide is intended for operators, installers and repair technician.

1.1 Conformity

The product is designed and was developed in conformity with the following directives and standards:

- Lift Directive 2014/33/UE
- EN81-2:1998 + A3:2009
- EN 81-20:2014
- EN 81-50:2014

1.2 Intended use

The type examined safety valve HSV is a component of the unintended car movement protection in down direction according to EN81-2:1998 + A3:2009, EN 81-20:2014 e EN 81-50:2014.

Combination of the safety valve HSV with a detecting component and actuating component, which are subject to approvals will constitute the complete protection, means that fulfils the requirements of a safety component.

If the current of HSV solenoid 12:A is correctly interrupted (see chapter 2.4.1.1) and all the operational limits are being observed (see chapter 2.5.1), the valve respects the requirements par., 5.6.7.5 e 5.6.7.6 EN 81-20:2014 independently of volume flow, load pressure and oil viscosity.

Hence proof of the function of the complete protection means can be provided by a travel at reduced speed (e.g. inspection speed).


The product must not handled in any way by unauthorised persons.

2 Description of Safety Valve HSV

2.1 Configurations

The Safety Valve HSV has two possible configurations:


Version flanged with control valve H300



**Version stand alone for all control valves
EN81-2**



2.2 Hydraulic and electrical diagram




2.3 Control Valve characteristics for connection with Security Valve HSV

Control Valve must satisfy the requirements of EN81.20:2014:

Paragraph on EN81-2	Description
5.9.3.5.2.1	A non-return valve shall be provided. It shall be installed in the circuit between the pump(s) and the shut-off valve.
5.9.3.5.3	A pressure relief valve shall be provided. It shall be connected to the circuit between the pump(s) and the non-return valve. The hydraulic fluid shall be returned to the tank.
5.9.3.5.4.1	Down direction valves shall be open electrically. Their closing shall be effected by the hydraulic pressure from the jack and by at least one guided compression spring per valve.
5.9.3.5.5	In the circuit between the tank and the pump(s), and in the circuit between the shut-off valve and the down direction valve(s), filters or similar devices shall be installed.
5.9.3.6	A pressure gauge shall be provided. It shall be connected to the circuit between the non-return valve or the down direction valve(s) and the shut-off valve.
5.9.3.9.1	The lift shall be provided with a manually operated emergency lowering valve allowing the car, even in the case of a power failure, to be lowered to a level where the passengers can leave the car.
5.9.3.9.1	For every lift whose car is fitted with a safety gear or a clamping device, a hand-pump which causes the car to move in the upward direction shall be permanently installed.

2.3.1 Example 1: control valve H300 hydraulic scheme with safety valve HSV



N°	Paragraph of EN81-2
1	5.9.3.5.2.1
2	5.9.3.5.3
3	5.9.3.5.4.1
4	5.9.3.5.5
5	5.9.3.9.1
6	12.9.1
7	5.9.3.9.2

2.4 Working description


The Safety Valve HSV is an electrically pilot operated check valve for hydraulic lifts. Installed between the cylinder and the lift valve it enables the oil flow from the lift valve A to the cylinder B during travel UP, and doesn't allow the flow in opposite direction (from B to A) until the pilot valve 12:A is energised.

2.4.1 Integration of the safety valve HSV into the lift control

2.4.1.1 State of the Safety Valve's solenoid vs. State of the lift

State of the lift	State of the solenoid valve			Remark
	Must be energised	Must be de-energised	Arbitrary	
Travel UP with door closed			X	No influence of the Safety Valve during travel UP
Travel DOWN with door closed	X			
Standstill with door open	X			For load pressure sensing and relevelling
Standstill with door closed, travel DOWN to start immediately	X			The Safety Valve must be energised at least 300 ms before travel starts, else the travel control of the lift valve can be affected adversely
Longer standstill period with door closed		X		For increase Energy Saving
Unintended travel UP with door open			X	No influence of the Safety Valve during travel UP, lift must be stopped by disconnection of the motors contactors
Unintended travel DOWN with door open		X		Interruption of the current to the solenoid of the Safety Valve when the unlocking zone is left(emergency stop); notes on the positioning of the shaft switches d_{max} (see chapter 2.3.1.3)
Hand pump operation			X	No influence of the Safety Valve during the travel UP
Emergency lowering, electrical	X			By means of the optionally available emergency power winding of the Safety Valve
Emergency lowering, manual			X	By means of manual release of the Safety Valve

2.4.1.2 Sequence of signals at normal operation for control valve H300




Legend:

Phase	Description	Remark
UP	12:A Motor 12:H	HSV solenoid 12:A can be energised Motor contactor ON High speed
DOWN	12:H 12:N 12:A * **	High speed Slow speed HSV solenoid 12:A must be energised 300 ms before energize 12:H and 12:N solenoid valves 1,5 s after de-energize 12:A solenoid valve

NOTE: with this configuration the Safety Valve HSV does not work as a redundant safety device, therefore does NOT require monitoring.

2.4.1.3 Sequence of signals at normal operation for control valve ESC




Legend:

Phase	Description	Remark
UP	12:A Motor	HSV solenoid 12:A can be energised
	12:H	Motor contactor ON High speed
DOWN	12:H	High speed
	12:N	Slow speed
	12:A	HSV solenoid 12:A must be energised
	*	300 ms before energize 12:H and 12:N solenoid valves
	**	1,5 s after de-energize 12:A solenoid valve

NOTE: with this configuration the Safety Valve HSV does not work as a redundant safety device, therefore does NOT require monitoring.

2.4.1.4 Sequence of signals at normal operation for control valve C-LRV



Legend:


Phase	Description	Remark
UP	12:A	HSV solenoid 12:A can be energised
	Motor	Motor contactor ON
	R2	Safety relay
	K1	“FAST up” signal
	K2	“SLOW up” signal
	*	Motor run-on time from 0.5 to 1 second
DOWN	R1	Safety relay
	K3	“FAST down” signal
	K4	“SLOW down” signal
	12:A	HSV solenoid 12:A must be energised
	**	1,5 s after open safety relay R1
	***	300 ms before activate R1,K3,K4 signals
	*****	1,5 s after stop signal K4

NOTE: with this configuration the Safety Valve HSV does not work as a redundant safety device, therefore does NOT require monitoring.

2.4.1.5 Positioning of the shaft switches d_{max}

$$x_{max} = v_{max} * t$$

$$d_{max} = 250 \text{ mm} - v_{max} * t$$



EN81-20:2014 paragraph 5.6.7.5 commands that the lift moving DOWN unintentionally with open door shall be stopped such that:

The distance between the floor of the car and the floor of the landing will not exceed 1200 mm.
The free distance from the car door lintel to the floor of the landing shall not be less than 1000 mm.

Both requirements must be fulfilled simultaneously. In order to exploit both criteria simultaneously the clearance height of the open door would have to be 2200 mm at minimum. The clearance height of many car doors is 2000 mm only. This reduces the maximum permissible distance between the floor of the car and the floor of the landing to 1000 mm.

The highest credible speed from which the lift must be stopped by the safety valve HSV is the speed slightly below the tripping speed of the gripping device or the pipe rupture valve. In the worst case this speed is 1,3 m/s.

The Safety Valve HSV is designed such that under consideration of a speed v_{max} of 1,3 m/s, maximum load and most unfavourable oil condition (low oil temperature), the lift will be stopped in 750 mm after de-energising of the solenoid of the safety valve HSV. hence the solenoid of the safety valve HSV must be de-energised when the lift has travelled no more than:

$$1000 \text{ mm} - 750 \text{ mm} = 250 \text{ mm}$$

The signal processing time t that it takes from the lift control to detect the travel with open door until the solenoid of the safety valve HSV is de-energised gives the distance travelled during signal processing x_{max} according to the formula:


$$x_{max} = v_{max} * t$$

v_{max} is the lift speed corresponding to the effective reaction flow of the rupture valve of the specific lift.

Hence the maximum permissible distance d_{max} between the shaft switch and the landing position is:

$$d_{max} = 250 \text{ mm} - v_{max} * t$$

2.4.1.6 Function of the Safety Valve HSV is case of an unintended travel DOWN



Legend:

Number	Description
1	HSV solenoid is energised
2	Shaft switch has tripped
3	Travel curve at unintended travel DOWN with maximum acceleration
***	300 ms before the travel commands DOWN get present

2.5 Technical data

2.5.1 Working limits

Specifications

Flow Range [l/min]	HSV-150 50 ÷ 150	HSV -440 150 ÷ 440 l/min
Operating pressures [bar]	10 ÷ 50	10 ÷ 50
Pressure drop A→B [bar]	< 1	< 3,7
Pressure drop B→A [bar]	< 1,5	< 5
Viscosity Range [cSt]	25-200	25-200
Temperature [°C] *	+ 5°C ÷ + 60°C	+ 5°C ÷ + 60°C
Admitted fluid	Hydraulic oil	Hydraulic oil

2.5.2 Port and Dimensions HSV-150 e HSV-440




Figure1




Figure2




Figure3

Type	Port A		Port B
	H300	Other control valve	All control valve
HSV-150	Flanged with 4 screws	Thread hole 1 ¼" Gas	- Flanged with shut-off valve 1", 1 ¼", 1 ½" Gas (Fig3) - Flanged with threaded flange connection 1", 1 ¼", 1 ½" Gas (Fig 2)
HSV-440	Flanged with 4 screws	Thread hole 1 ¼" Gas	- Flanged with shut-off valve 1", 1 ¼", 1 ½" Gas (Fig3) - Flanged with threaded flange connection 1", 1 ¼", 1 ½" Gas (Fig 2)

Type	Model		C [mm]	L [mm]	P [mm]
	Code	Description			
HSV 150	8690503	Mono-solenoid	173	197	78
	8690505	Bi-solenoid	213	197	78
HSV-440	8690504	Mono-solenoid	173	197	78
	8690506	Bi-solenoid	213	197	78

2.5.3 Label


The two different type of HSV valve are identifiable by the following label fixed directly on the valve.

HM-SV 150	HM-SV 440
 Hydronic Lift S.p.A. Via Perin del Vaga, 12 20156 MILANO (ITALY) Type: HSV 150 Certificate n° EQSCH 001 Flow range 50 - 150 l/m Pressure range 10 - 50 bar CE 0948 	 Hydronic Lift S.p.A. Via Perin del Vaga, 12 20156 MILANO (ITALY) Type: HSV 440 Certificate n° EQSCH 001 Flow range 150-440 l/m Pressure range 10 - 50 bar CE 0948 

2.5.4 Solenoid's wiring


Version without emergency power winding:

MAIN COIL POWER WINDING 12:A




Version with emergency power winding (optional):

MAIN COIL POWER WINDING 12:A



EMERGENCY POWER WINDING 12:AA



(* : any polarity)

Connection color identification:

BN: brown

BU: blue

GNYE: green-yellow

Type	Voltage main coil winding	Voltage emergency power winding	Max. Power consumption
24 VdC 50 Hz	24 VdC $\pm$ 10%	-	37 W
48 VdC 50 Hz	48 VdC $\pm$ 10%	-	37 W
90 VAC 50 Hz	90 VAC $\pm$ 10%	-	37 W
110 VAC 50 Hz	110 VAC $\pm$ 10%	-	37 W
220 VAC 50 Hz	220 VAC $\pm$ 10%	-	41 W
24/12 VdC 50 Hz	24 VdC $\pm$ 10%	12 VdC $\pm$ 10%	37 W / 45 W
48/12 VdC 50 Hz	48 VdC $\pm$ 10%	12 VdC $\pm$ 10%	37 W / 45 W
48/24 VdC 50 Hz	48 VdC $\pm$ 10%	24 VdC $\pm$ 10%	37 W / 50 W
90/12 VAC 50 Hz	90 VAC $\pm$ 10%	12 VdC $\pm$ 10%	37 W / 45 W
90/24 VAC 50 Hz	90 VAC $\pm$ 10%	24 VdC $\pm$ 10%	37 W / 50 W
110/12 VAC 50 Hz	110 VAC $\pm$ 10%	12 VdC $\pm$ 10%	37 W / 45 W
110/24 VAC 50 Hz	110 VAC $\pm$ 10%	24 VdC $\pm$ 10%	37 W / 50 W
220/12 VAC 50 Hz	220 VAC $\pm$ 10%	12 VdC $\pm$ 10%	37 W / 45 W
220/24 VAC 50 Hz	220 VAC $\pm$ 10%	24 VdC $\pm$ 10%	41 W / 50 W

NOTE 1: *simultaneous energising of the main coil winding and emergency power winding will overheat the solenoid. Never energising the main coil winding and the emergency power winding simultaneously.*

NOTE 2: *the plug of the solenoid is potted into the coil socket together with a rectifier. The attempt to remove the plug will destroy the solenoid. By no means detach the plug from the solenoid.*

2.5.5 Pressure switch

2.5.5.1 Pressure switch selection

Description	Function	Tolerance at 25°C	Maximum pressure
20-70	Normally open	± 1 bar	300 bar
20-70	Normally close	± 1 bar	300 bar
0-10 for rupture valve	Normally open	$\pm 0,3$ bar	300 bar

2.5.5.2 Configuration with safety valve HSV

1. Configuration with one pressure switch



2. Configuration with two pressure switches



3. Configuration with three pressure switches



3 Installation and commissioning

3.1 Electrical installation

1. Connect the solenoid of the Safety Valve to the lift control.

NOTE: *incorrect wiring will damage the solenoid. Connect voltages only according to the type of the solenoid coil and the prescribed wire assignment.*

3.2 Start up

1. During the lift's installation, it's need to make a couple runs in up and down direction, pressing at the same time the two down manual lowering valve to purge the air inside the valve HSV
2. When installation works are done, prior to commissioning the lift, execute the first maintenance of the Safety Valve (see chapter 5).

4 Installation as modernization kit


4.1 Mechanical installation of safety Valve HSV

4.1.1 Mechanical installation with control valve H300



The installation of HSV Safety Valve with control valve H300 is provided with a flanged connection.

Follow the procedure described below:



- 1) Lead the lift to ground floor and shut off the control panel. Close the H300 shut-off valve and remove pressure by pushing the manual lowering:



- 2) Remove the M10 screw (as illustrated into the figure) and remove the handle of shut-off valve:




3) Remove the shut-off valve unscrewing the 4 screws M8:




4) Verify into the HSV Safety Valve kit are present:

- n°1 HSV Safety Valve
- n°1 Solenoid Coil
- n° 1 O-ring 3181 d=45.69 x 2.62
- n°4 Screws M8 x 90 UNI 5981 8.8





Before installing the HSV valve, remove the two plastic plugs that protect the holes for oil inlet and outlet.


- 5) Verify that the provided O-Ring is correctly positioned in its seat and then flange the HSV Safety Valve on the control valve H300 with the 4 provided screws M8x90:



- 6) Install the shut-off valve by using the 4 screws M8 x 70 and the o-ring removed at point 3:



- 7) Restore the handle of shut-off valve:



- 8) Open the shut-off valve and restore the pressure into the valves. Provide to the electrical wiring of HSV (see paragraph 2.5.4).

NOTE: *before start up the lift execute the procedure described in paragraph 3.2*

4.1.2 Mechanical installation with control valve C-LRV

The installation of Safety Valve HSV with control valve C-LRV is provided with a nipple adaptor with rotating nut. It's possible choose two different configurations (see paragraph 2.5.2):

Shut-off valve





Threaded flanged connection



Follow the procedure described below:


- 1) Before install HSV valve is necessary to empty the jack and flex hose from oil, then shut off the control panel.
- 2) Remove the shut-off valve and then the connection nipple with C-LRV valve:





- 3) To allow the connection between the Safety Valve HSV and the control valve C-LRV is provided a nipple adaptor of 1 ¼ “(already installed on HSV valve) and an adaptor nipple (if required) depending on size of C-LRV valve:

C-LRV 175	1 ¼ “→ 1”
C-LRV 350	1 ½ “ → 1 ¼ “


and a bonded seal. Screw the nipple as the below scheme:




- 4) Install the HSV valve:



- 5) When the Safety Valve HSV is provided with the flanged connection re-install the shut-off valve removed at point 2. Be careful to insert the bundled seal between flange and shut-off valve (see figure below):



If the HSV valve is provided with shut-off valve see the next point.



- 6) Connect the main pipe and restore pressure into the hydraulic circuit.

NOTE: before start up the lift execute the procedure described in paragraph 3.2



4.2 Change of pressure switch position

NOTE: *before execute any operation remove pressure from both two valves, close the shut off valve and push at the same time the manual lowering of control valves and HSV valves and remove the connection of pressure switch.*

4.2.1 H300 control valve



4.2.1.1 Single pressure switch configuration.

Unscrew the pressure switch (position 1) and remove the plug (position 2) screwed on to HSV valve. Then screw the pressure switch with the related bounded seal into position 2 and screw the plug into position 1.




4.2.1.2 Double pressure switches configuration.

Unscrew the pressure switches (position 1 and 2) and remove the plugs (position 3 and 4) screwed on to HSV valve. Then screw the pressure switches with the related bounded seals into position 3 and 4, then screw the plugs into position 1 and 2.



4.2.1.3 Triple pressure switches configuration.



Unscrew the pressure switches (position 1 and 2) and remove the plugs (position 3 and 4) screwed on to HSV valve. Then screw the pressure switches with the related bounded seals into position 3 and 4, then screw the plugs into position 1 and 2.



4.2.2 C-LRV control valve



4.2.2.1 Single pressure switch configuration.

Unscrew the pressure switch (position 1) and remove the plug (position 2) screwed on to HSV valve. Then screw the pressure switch with the related bounded seal into position 2 and screw the plug into position 1.





4.2.2.2 Double pressure switches configuration.

Unscrew the pressure switches (position 1 and 2) and remove the plugs (position 3 and 4) screwed on to HSV valve. Then screw the pressure switches with the related bounded seals into position 3 and 4, then screw the plugs into position 1 and 2.



4.2.2.3 Triple pressure switches configuration.

Unscrew the pressure switches (position 1 and 2) and remove the plugs (position 3 and 4) screwed on to HSV valve. Then screw the pressure switches with the related bounded seals into position 3 and 4, then screw the plugs into position 1 and 2.




5 Operation

5.1 Normal operation

1. To enable travel DOWN either the main coil winding 12:A or the emergency power winding 12:AA of the HSV valve must be energised by the lift control at the right time (see paragraph 2.4.1.1).
Beyond those, no parts have to be operated during normal operation of the lift.

5.2 Manual operation

1. Observe the instruction in the lift documentation or in the lift valve documentation for an execution of the manual emergency lowering.
2. Push the knob (see figure below) on the solenoid 12:A of the Safety Valve at the same time of the control valve's manual lowering (see the below example with H300).



3. Control the travel by operation of the manual lowering valve on the lift valve until the landing intended for the evacuation of the car is reached.
4. When the lift has stopped release the knob.

NOTE: *the manual operation knob can get hot if the solenoid of the safety valve is energised over a longer period of time. If there is a suspect that the knob is hot pull the knob only with the aid of either a sufficiently insulating glove or tool.*

6 Check the correct functioning of HSV valve

The obliged maintenance intervals are:

- First time at the start up
- After 3 months
- Every 6 months

The principal maintenance tasks are:

- Leakage test of the valve seat
- Cleaning the pilot filter and the nozzle
- Simplified functional test

6.1 Leakage test of the valve seat

1. Observe the instructions in the lift, or in the lift valve documentation, for the operation of the manual emergency lowering valve.
2. Make sure that the lift is stopped at the place at which the position of the car can be determined with sufficient accuracy
3. Wait 5 seconds to verify that the cabin remains at the floor

NOTE: the plug of the solenoid is potted into the coil socket together with a rectifier. The attempt to remove the plug will destroy the solenoid. Don't detach the plug from the solenoid.

4. Make sure that both the main coil winding 12:A and the emergency power winding 12:AA (optional) of the HSV valve are **NOT** energised.
5. Energize the down solenoid valve of the main control valve (12:N for H300 valve), ensuring that the solenoid valve 12:A and 12:AA (if present) of the HSV valve are **NOT** energized.
6. Must check:
 - a. the indication on the manometer of the lift valve drops to zero
 - b. after that the car doesn't move in a visible manner any more
7. When no visible movement of the car has been determined:
 - a. De-energize the down solenoid valve of the main control valve (12:N for H300 valve)
 - b. Make sure that both the main coil winding 12:A and the emergency power winding 12:AA (optional) of the HSV valve are properly connected to the lift control again

If the procedure is done correctly the leakage test has been passed successfully .

8. When the car moves in a visible manner:
 - Put the emergency lowering valve on the lift valve back to its resting position

- Withdraw the lift from service
- Replace the defective Safety Valve
- Execute the test again

6.2 Simplified functional test

1. Execute a travel DOWN at the inspection speed and disconnect the power supply to the main coil winding of the solenoid of the Safety Valve during travel. Provided that the Safety Valve works properly the car will stop under all circumstances after 750 mm at the latest.
2. Make sure that the main coil windings and the emergency power winding (optional) of the solenoid of the Safety Valve are properly connected to the lift control again

7 Repair



Except for the 12:A solenoid coil the Safety Valve has no user detachable or lift service detachable parts. Any dismantling or repair of the Safety Valve beyond the replacement of the solenoid coil (see chapter 6.1) must be executed by HL customer service only.

7.1 Replacement of the solenoid coil

NOTE 1: the plug of the solenoid is potted into the coil socket together with a rectifier. The attempt to remove the plug will destroy the solenoid. Don't detach the plug from the solenoid.

NOTE 2: the solenoid of the Safety Valve can get hot if it's energised over a long period time. Prior starting the work make sure that the solenoid has cooled down



1. Make sure that the main coil windings is disconnected from the lift control.
2. Unscrew the bolt (4) that links the plug (5) to the coil (3).



3. Remove the plug (5) from the coil (5).
4. Slide the new solenoid coil (3) onto the solenoid tube (1)



5. Link the cable to the coil (3) with the plug (5) and screw the bolt (4)



6. Connect the solenoid coil (3) to the lift control



M - 00 – 019
Rev: 10
Data: 17/10/2019
Page 37/40



M - 00 – 019
Rev: 10
Data: 17/10/2019
Page 38/40



M - 00 – 019
Rev: 10
Data: 17/10/2019
Page 39/40

For further information and advice contact:

Hydronic Lift s.p.a.

Factory: Via per Cadrezzate, 21/C4 Cap:21020 Brebbia (Varese) ITALY

Tel. +39 0332773134

Fax. +39 0332773157

e-mail: hydronic@hydroniclift.it

Site: www.hydroniclift.it